


BC 60 control valve—parts and their locations



- | | | |
|---|---|---|
| 1. Cylinder port B | 6. Adjusting screw for servo pressure | 11. Thomas solenoid |
| 2. Cylinder port A | 7. Main relief valve | 12. Junior Power Time connector (Tyco 282189-1) |
| 3. Port reliefs | 8. Adjusting screw for main relief valve pressure setting | 13. Limiting screw for spool movement |
| 4. Pressure adjusting of port relief | 9. Fastening screw for thomas solenoid | 14. Spring cup |
| 5. Pressure reducing valve for servo pressure | 10. For measuring servo pressure (in a LS-valve: connection to LS-line) | 15. Alternatives for pressure connection |